



USE A 1/8" DRILL BIT FOR A PILOT HOLE FOR THE PIVOT BRACKET MOUNTING SCREWS

D4 = 8 1/2" [216mm]
(Minimum distance 7 1/2" [190mm])

!BEFORE DRILLING!

1. Verify the center of the pin is equal distance from the corners of the cabinet. $D_1=D_2=D_3$
2. Place the (J) Shelf over the center to ensure the assembly is properly centered and fits in the cabinet properly

FRAMELESS 36" CABINET EDGE

FRAMED 36" CABINET EDGE (WOOD TRIM FACE)



Not-So-Lazy Susan™
Center Pin Mounting Template

For questions or video instructions go to www.glideware.com